





USER MANUAL

XB- Series ball head

Thank you for purchasing the leofoto XB series ball head. Please read this manual before use.



2 Operation



1) Mounting onto the tripod

Fig. 1 Screw the ball head (panning base tightened) clockwise onto the tripod (use 3/8"-16 bushing reducer if the tripod has a UNC 1/4"-20 mounting stud).

2) Panning base operation

Fig. 2 Loosen the panning base knob by turning anticlockwise and rotate the head body with one hand to adjust the panning position, the other hand holds the camera for security.

3) Main lock knob and tension setting knob

Fig.3 Loosen the main! lock knob properly(you can adjust the position of the camera while it won't move when you put your hands down. Turn the friction knob clockwise until it stops and you may loosen the main lock knob completely next time when you want to adjust the position) and adjust the position to frame, lock the main lock knob and then begin the shooting.

3 Features:



4 Maintance

- No extra lubrication;
- 2) Prevent the macro focusing rail from getting fouled in mud, dirt or sand;
- 3) Blow off the sand or dust, or wipe off with the cotton cloth;
- 4) Rinse off the mud or salt water with a wet cloth and then thoroughly dry;

5 Remarks

- 1) Working temperature: -30" to 60";
- 2) It is advisable to loosen the knobs when you do not use it for long periods;
- Every time you move the tripod or the ball head, removing or holding the camera equipments to make sure the camera security;
- 4) Leofoto Provides for the base a 7-day money -back guarantee and 1-year standard warranty;

Design and specifications are subjuect to change without notice

Zhongshan Laitu Photographic Equipment Co., Ltd

No.6 Weiye Road, Pingdong Industrial Zone, Sanxiang Town, Zhongshan City, Guandong, P.R.China Zip:528463 Tel:+86-760 85885368 Fax:+86-760 85885228 www.leofoto.com