




User Guide



SID 

3D Camera


WV3000

Over View

Weeview's SID Camera offers high resolution 3D video and 3D photo, and live stream in 3D with compatible streaming software. Viewers can truly re-live and re-define the experience.

Specification

Video max resolution	3K (2880x1440) / 30fps
Photo max resolution	32M (8064x4032)
Lens	FOV 160 / F2.4
Dimensions	80x40x19.5 (mm)
Weight	60g
Interface	Wi-Fi 802.11n / Micro USB2.0 / Micro SD
SD storage	Support to 128G
Battery	1300 mAh
USB	MSDC mode / UVC1.1 mode



1 Snap key

2 Mode light

3 Wi-Fi key

4 Power key / Battery, Charging light / Video, Photo mode switch

5 Error light

6 USB port

7 Memory card slot

8 Reset key


Caution

1. The battery used in this device may present a fire or chemical burn hazard if mistreated.
2. Do not leave the device in environment of over 50C (122F).
3. Avoid high impact of the device.
4. Keep form children and pets.
5. Do not expose this device to rain or moisture.
6. Do not dispose of the device as household waste. For disposal or recycle information please contact your local authorities.

Connect Wi-Fi (iOS)


1 Turn on the SID Camera

Press the power key and hold until the device with beeps sound and LED turn on.




2 Turn on Wi-Fi of SID Camera

Press the Wi-Fi key once and Wi-Fi LED turn on.



3 Select Wi-Fi

Go to iOS settings and turn on Wi-Fi. Connect to the 'SID_XXXXXXXXXXXX' Wi-Fi network and enter the default password (12345678).




Once connecting successfully, Wi-Fi LED will start to flash.



Connect Wi-Fi (Android)


1 Turn on the SID Camera

Press the power key and hold until the device with beeps sound and LED turn on.




2 Turn on Wi-Fi of SID Camera

Press the Wi-Fi key once and Wi-Fi LED turn on.




3 Select Wi-Fi

Open SID Camera app.



Click the 'SID_XXXXXXXXXXXX' Wi-Fi network and enter the default password (12345678).



Once connecting successfully, Wi-Fi LED will start to flash.



Change Video/Photo Mode

Change Video/Photo Mode

Press the power key once.






Photo Mode




Video Mode



Live Stream

1 Connect to PC

Connect SID to PC with USB cable.
Turn on SID Camera,
'Video, Photo and Live' lights illuminate.




Computer Suggestion:

1. Use Windows® 7 64 bits or Windows® 10 64 bits Operation System.
2. Download and install K-lite codec Pack full version from https://www.codecguide.com/download_kl.htm to enhance UVC frame rate to 30 fps.
3. Download and install OBS(Open Broadcaster Software) software from <https://obsproject.com/>


2 Change to UVC Mode

Press the power key once, only 'Live' light illuminates.




3 Active Live Stream Mode


Press the snap key once,
'Video and Live' lights illuminate.




4 Open OBS(Open Broadcaster Software)




1 Sources > + > Video Capture Device



2 Create new > OK



3 Adjust red line area to fit the black screen




4 Follow the OBS instruction to send SID live streaming to social media.

Mass Storage

1

Connect to PC


Connect SID to PC with USB cable.
Turn on SID Camera,
'Video, Photo and Live' lights illuminate.



2


Active Mass Storage Mode

Press the snap key once, only 'Video' light illuminates.




Battery Indicator


1 Full Battery - Blue Light



2 Medium Battery - Purple Light




3 Low Battery - Red Light



Memory Error Indicator

Memory Error - Red Light



Note

Improvements and changes to this user guide necessitated by typographical errors, or improvements to programs, may be made by Weeview Inc. At any time and without notice. For latest information please visit Weeview official website

(www.weeview.co/eng/index.php).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body and must not be collocated or conjunction with any antenna or transmitter.

Warning

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: The device needs to reboot under electrostatic operation.

To ensure a highly quality recording, you are suggested to use TF card with Class10 or above.

本產品符合低功率電波輻射性電機管理辦法：

第十二條

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

